



10



B

A


P9




11





- ▷ Voir Mode d'emploi de la pompe Flygt SXM2GT
- ▷ See Instructions for use and technical Flygt SXM2GT
- ▷ Sieh Gebrauchsanweisung Flygt SXM2GT



12




13














14


- NI 005  
BR-S 1500  
BR-L 2000  
BR-E 3000
- NI 019  
BR-F 5000  
BR-G 5000





KIT SORTIE HAUTE SANS ALARME : INSTALLATION DE LA POMPE  
BAUSATZ OBERER AUSGANG OHNE ALARM : ABWASSERPUMPE & ANSCHLÜSSE  
HIGH OUTLET KIT WITHOUT ALARM : PUMP INSTALLATION & ASSEMBLE



P1



1



2

